



## **Installer / Windows® Printer Driver & Firmware Instructions**

Vivo!

1. Click the **Download** button and save the file to a folder on your computer.
2. When it finishes downloading, **Run** the executable by double-clicking on the file that you saved.
3. **Extract** the files to the same folder that contains the original file downloaded. You may need to browse to this folder before extracting the files.
4. You can now burn the contents of this folder to a CD or simply **double-click on the autorun.exe file to run** the Vivo! Installer CD.

**Color Profiles:** Run the autorun.exe file and click the Install Color Profiles button to run the utility that installs the new color profiles.

**WARNING:** If you have FEEDER VIVO V2 (as noted on serial tag) please review the HTM files on the CD for installing the V2 Driver and initializing the V2 Vivo! System.